



PCM Engine Wiring Diagram

Notes:

1. Ford Non-Solenoid Type Starter (1 wire)
2. Voltmeter Configuration (No Ammeter)
3. Internally Regulated Alternator
4. Harness Pin-out: